

PARADOX[®] ELECTRO[®]

Distributed by Syndicate Paintball, LLC

CAUTION

- READ THIS ENTIRE OWNERS MANUAL PRIOR TO USING THIS PRODUCT.
- YOU MUST BE AT LEAST 18 YEARS OF AGE TO USE OR BUY THIS PRODUCT OR BE ACCOMPANIED BY AN A PARENT OR LEGAL GUARDIAN AT TIME OF PURCHASE OR PLAY.
- THIS PAINTBALL MARKER IS NOT A TOY. MISUSE OF THIS PRODUCT COULD RESULT IN SERIOUS INJURY OR DEATH. PROPER FACE, THROAT, EAR AND EYE PROTECTION SPECIFICALLY DESIGNED FOR THE SPORT OF PAINTBALL SHOULD ALWAYS BE WORN DURING THE OPERATION OF THIS PRODUCT.
- THE BARREL PLUG SHOULD BE INSERTED INTO THE MARKER AT ALL TIMES WHEN THE MARKER IS NOT BEING USED IN PLAY.
- NEVER POINT A LOADED AND GASSED MARKER AT ANYONE AT ANY TIME THAT IS NOT WEARING PROPER FACE, THROAT, EAR AND EYE PROTECTION SPECIFICALLY DESIGNED FOR THE SPORT OF PAINTBALL.
- PEOPLE IN THE IMMEDIATE ARE OF THE MARKER (WHILE IT IS BEING USED) SHOULD WEAR PROPER SAFETY GEAR DESIGNED FOR THE SPORT OF PAINTBALL.
- THIS PRODUCT IS DESIGNED, TO USE .68 CALIBER PAINTBALLS ONLY. DO NOT USE ANY OTHER OBJECTS TO BE PROPELLED FROM THE UNIT.

○ IMPORTANT NOTICE

- DO NOT USE THIS MARKER TO SHOOT AT A TARGET CLOSER THAN 20 FEET.
- THIS MARKER IS DESIGNED TO SHOOT AT A VELOCITY OF AROUND 300 FEET PER SECOND (FPS). THIS VELOCITY MAY BE AFFECTED BY ALTTITUDE AND TEMPERATURE. IT IS RECOMMENDED THAT THIS MARKER NOT BE SHOT AT A VELOCITY HIGHER THAN THAT OF 280 FEET PER SECOND (FPS). PLEASE USE A PAINTBALL CHRONOGRAPH TO CHECK YOUR VELOCITY PRIOR TO PLAY.